


Exploded View

Indoor Unit 12K

No.	Part Name	Code	Q'ty
1	panel	RO-A-A-11320003003697	1
2	air louver (Horizontal)	RO-A-A-11320005000446	1
3	display board	RO-A-A-1122014000804	1
4	filter	RO-A-A-11220508000192	1
6	Screw cover	RO-A-A-11320096000120	1
7	medium frame	RO-A-A-11320002000411	1
8	chassis assembly	RO-A-A-11220500000374	1
8.1	left-right swing blade	RO-A-A-11320017000185	1
8.2	volute	RO-A-A-11320135000030	1
8.3	chassis	RO-A-A-11320001000314	1
8.4	stopple	RO-A-A-11333003000009	1
8.6	step motor shaft sleeve	RO-A-A-11320079000016	1
8.8	main air blade	RO-A-A-11320017000186	1
9	bearing fixed chassis	RO-A-A-11320062000028	1
10	bearing assembly	RO-A-A-11220551000003	1
11	cross flow fan	RO-A-A-11220513000081	1
12	Evaporator assembly	RO-A-A-11224003000970	1
12.1	evaporator left side carriage	RO-A-A-11320015000176	1
12.2	Evaporator assembly	RO-A-A-11224009000446	1
12.3	evaporator assembly	RO-A-A-11224009000463	1
13	indoor fan motor	RO-A-A-11230005000074	1

No.	Part Name	Code	Q'ty
14	motor cover	RO-A-A-11320052000058	1
15	mounting plate assembly	RO-A-A-11221500000039	1
16	pipe clamp	RO-A-A-11320084000013	1
17	main controller	RO-A-A-11222003004099	1
17.1	controller box sheet-metal	RO-A-A-11321101000004	1
17.2	controller box	RO-A-A-11320057000138	1
17.3	Main control board	RO-A-A-11222009004199	1
17.6	terminal board	RO-A-A-11330037000184	1
18	wire clamp	RO-A-A-11320046000011	1
20	Middle frame wiring cover fireproof board	RO-A-A-11321086000002	1
21	Remote controller	RO-A-A-11222001000112	1
22	water flow tube assembly	RO-A-A-11220506000013	1
23	water hosepipe	RO-A-A-11220506000013	1
25	power cable	RO-A-A-11330021001109	1



Exploded View

Outdoor Unit 12K

No.	Part Name	Code	Q'ty
1	right side board	RO-A-A-11321157000066	1
2	crimping cover base	RO-A-A-11320120000004	1
4	ground plate	RO-A-A-11321015000084	1
5	E-parts cover	RO-A-A-11321008000015	1
7	valve plate	RO-A-A-11321031000034	1
8	stop valve	RO-A-A-11225517000084	1
9	stop valve	RO-A-A-11225517000076	1
10	Chassis assembly	RO-A-A-11221502000075	1
10.1	chassis	RO-A-A-11321014000063	1
10.2	base footing	RO-A-A-11321023000020	2
10.4	compressor footing bolt	RO-A-A-14731005000063	3
11	Compressor and accessories	RO-A-A-11223004000041	1
12	panel grille	RO-A-A-113210220000275	1
13	panel	RO-A-A-113210050000145	1
14	axial flow fan	RO-A-A-113200090000074	1
15	left side board	RO-A-A-11321156000017	1
16	motor	RO-A-A-112300050000071	1
17	motor support	RO-A-A-11321002000045	1

No.	Part Name	Code	Q'ty
16	Condenser assembly	RO-A-A-112240040001990	1
17	condenser assembly	RO-A-A-112240060000603	1
18	Capillary assembly	RO-A-A-112255060002151	1
19	condenser lug	RO-A-A-113210290000057	1
19.1	top cover	RO-A-A-113210090000062	1
19.2	Isolation of cardboard	RO-A-A-113320090000044	1
20	suction pipe assembly	RO-A-A-112255040001008	1
22	discharge pipe assembly	RO-A-A-112255050001124	1
23	partition board	RO-A-A-113210250000083	1
23.2	Main controller	RO-A-A-112220040001308	1
23.3	Main control board	RO-A-A-112220310001400	1
23.4	control box	RO-A-A-113200570000136	1
24	terminal board	RO-A-A-113300370000157	1
26	accessory bag	RO-A-A-112190050000166	1
26.1	putty	RO-A-A-146180790000002	1
27	plastic tie	RO-A-A-113200220000019	1
28	temperature sensor	RO-A-A-113290130000118	1

