


Exploded View Indoor Unit 18K

No.	Part Name	Code	Q'ty
1	panel	RO-A-A-11320003003715	1
2	display board	RO-A-A-11222014000804	1
3	air louver (Horizontal)	RO-A-A-11320005000470	1
4	Screw cover	RO-A-A-11320096000104	2
5	filter	RO-A-A-11220508000200	1
6	medium frame wiring cover	RO-A-A-11320076000125	1
7	medium frame assembly	RO-A-A-11220501001009	1
7.1	medium frame	RO-A-A-11320002000421	1
8	Evaporator assembly	RO-A-A-11224003000882	1
8.1	evaporator left side carriage	RO-A-A-11320015000122	1
8.2	evaporator assembly	RO-A-A-11224009000221	1
8.2	evaporator assembly	RO-A-A-11224009000462	1
8.3	evaporator protecting bush	RO-A-A-11320101000030	1
9	bearing fixed chassis	RO-A-A-11320062000026	1
10	bearing assembly	RO-A-A-11220551000003	1
11	cross flow fan	RO-A-A-11220513000058	1
12	chassis assembly	RO-A-A-11220500000291	1
12.1	chassis	RO-A-A-11320001000317	1
12.2	stopple	RO-A-A-11333003000009	1

No.	Part Name	Code	Q'ty
12.3	air louver	RO-A-A-11320135000023	1
12.4	left-right swing blade	RO-A-A-11320017000152	3
12.5	manual air guide link	RO-A-A-11320085000103	1
13	mounting plate assembly	RO-A-A-11221500000040	1
14	pipe clamp	RO-A-A-11320084000015	1
15	air louver step motor	RO-A-A-11320002000152	1
16	step motor shaft sleeve	RO-A-A-11320079000016	1
17	Main controller	RO-A-A-11222003004110	1
17.1	control box	RO-A-A-11320057000141	1
17.4	temperature sensor	RO-A-A-11329013000103	1
17.5	terminal board	RO-A-A-11330037000184	1
18	power wire cable clamp	RO-A-A-11320046000011	1
20	IDU fan motor	RO-A-A-11230005000072	1
22	motor cover(in)	RO-A-A-11320087000031	1
22	motor cover(in)	RO-A-A-11320087000030	1
23	motor cover	RO-A-A-11320052000062	1
25	Remote controller	RO-A-A-11222001000112	1
26	power cable	RO-A-A-11330021001109	1
27	Drain pipe assembly	RO-A-A-11220506000013	1
28	drain hose	RO-A-A-11320020000008	1



Exploded View Outdoor Unit 18K

No.	Part Name	Code	Q'ty
1	right side panel	RO-A-A-11321157000068	1
2	crimping cover base	RO-A-A-11320120000004	1
3	crimping cover	RO-A-A-11320046000004	1
4	ground plate	RO-A-A-11321015000084	1
5	E-parts cover	RO-A-A-11321008000015	1
7	valve plate	RO-A-A-11321031000034	1
8	stop valve	RO-A-A-11225517000084	1
9	stop valve	RO-A-A-11225517000085	1
10	Chassis assembly	RO-A-A-11221502000078	1
10.1	chassis	RO-A-A-11321014000164	2
10.2	base footing	RO-A-A-11321023000019	3
10.3	compressor footing bolt	RO-A-A-14731005000063	1
11	Compressor and accessories	RO-A-A-11223003000414	1
12	panel grille	RO-A-A-11321022000274	1
13	panel	RO-A-A-11321005000149	1
14	axial flow fan	RO-A-A-11320009000076	1
15	motor	RO-A-A-11230005000078	1
16	motor support	RO-A-A-11321002000049	1

No.	Part Name	Code	Q'ty
17	left side board	RO-A-A-11321156000020	1
18	condensor assembly	RO-A-A-11224004001982	1
18.1	condensor assembly	RO-A-A-11224006000064	1
18.2	capillary assembly	RO-A-A-11225506000217	1
19	top cover	RO-A-A-11321009000063	1
20	Isolation of cardboard	RO-A-A-11320090000046	1
21	partition board	RO-A-A-11321025000085	1
22	main controller	RO-A-A-11222004001382	1
22.2	control box	RO-A-A-11320057000137	1
22.3	Main control board	RO-A-A-11222031001455	1
22.4	terminal board	RO-A-A-11330037000157	1
23	discharge pipe assembly	RO-A-A-11225505000125	1
24	suction pipe assembly	RO-A-A-11225504001010	1
25	accessory bag	RO-A-A-11219005000166	1
25.1	putty	RO-A-A-14618079000002	1
26	plastic tie	RO-A-A-11320022000019	1
27	temperature sensor	RO-A-A-11329013000118	1

